Thank you for purchasing a Secret Spanks Footstool/Bench Bench assembly Instructions:

Slide the lid off the box and remove the Knee Pad



Inside the box you should find:

- 4 x legs
- 2 x wooden cross pieces
- 2 x metal cross pieces
- 1 x bag containing 4 short bolts, 8 long bolts, 16 wing nuts & 16 washers



Remove the wooden and metal cross pieces and the bag of bolts and nuts Remove the legs by tilting them up and sliding them out at an angle



Place the legs on the ground with the cut-outs on the bottom



You will notice that there are small coloured stickers on the legs. These show which pieces go together.



Put the short bolts in the holes of the cut-outs Put the legs together with the same coloured dots against each other.



Put the two wooden cross pieces into the cut outs and loosely fit the washers and nuts



Place the metal cross pieces with 4 long bolts as shown. Again loosely fit the washers and nuts



Fit the knee pad, it will only fit into one set of holes. Again loosely fit the washers and nuts



Place the box onto the legs and align the holes, then place the remaining 4 long bolts through as shown.



Fit the remaining nuts and washers. You may now tighten up all the nuts. Slide the box lid back on